

Coffee preparation



Fill the water tank



Switch the machine on




Flashing light : heating up
Steady light: ready



Lift the lever completely
and insert a nespresso capsule



Close the lever and place
a cup under the coffe
outlet



Espresso button (small cup)
Lungo button (large cup)



Enjoy

Tea preparation



Fill the water tank



Switch the machine on



Flashing light : heating up
Steady light: ready



Place the cup and press once the small coffee button
to drain the water.



Remove and empty the
cup.



Espresso button (small cup) - Lungo button (large cup)



Enjoy